



PO Box 7277
Algonquin, IL 60102
800.801.7832 - 847.639.7272
support@4progressive.com
www.4progressive.com

Progressive
Solutions Corporation

providing "PROGRESSIVE SOLUTIONS" for your industry.

KLEEN KOTE™ - Agriculture and Hauling Equipment Instructions

- **Instructions for Using KLEEN KOTE On Hauling Equipment, Mower Decks, Hoppers, Manure Spreaders and Combines**
 - **Mix Ratio 8 to 1 thru 11 to 1 -- Depending Upon Results**
 - Use KLEEN KOTE to keep mud, debris, agricultural products, snow, salt and ice from sticking to hauling equipment, mower decks, hoppers, manure spreaders, snow plow blades and combines. It is an environmentally safe alternative to traditional release agents, diesels or other fuels. It also provides rust inhibiting qualities to help prevent corrosion.
- **Tips for Use**
 - Remove all previous release agents or coatings from the equipment prior to applying KLEEN KOTE to eliminate any adverse reaction between KLEEN KOTE and the previous coating.
 - For debris, agricultural products, mud and snow hauling, spray KLEEN KOTE once a day prior to your first use. In freezing weather, the bed or equipment must be warmed indoors prior to applying KLEEN KOTE.
 - KLEEN KOTE must turn from white to clear after it is sprayed on the bed before you start hauling.
 - If you wash the equipment with soap and water, you must re-apply KLEEN KOTE before hauling your next load.
- **Instructions**
 - **Step 1 – Determine Your Mix Ratio**
 - Please see the above starting mix ratios. Ratios can be adjusted based upon your results. They may be adjusted up or down in one part increments to achieve optimum results.
 - NOTE: The more concentrate you add the thicker and more protective KLEEN KOTE will be.
 - **Step 2 – Mixing**
 - Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing. Do NOT mix with diesel, fuels or oils. Do NOT mix with other release agents or chemicals.
 - **Step 3 – Application**
 - KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to application. Remove all other release agents and chemicals before applying KLEEN KOTE.
 - **Step 4 – Spraying**
 - Spray on and then let change from white to clear before using the treated equipment. If KLEEN KOTE freezes on the surface you are treating, it will still work for certain applications. Reapply after every use.
 - **Typical Coverage Rates**
 - 1 gallon of mixed KLEEN KOTE will cover approx. 2000 square feet, depending on the surface type. Spray on for best performance and ease of application.
- **Notes**
 - DO NOT switch back and forth between KLEEN KOTE and other release agents due to possible incompatibilities.
 - You do not have to wait for the bed or equipment to dry after cleaning. KLEEN KOTE may be applied directly to a wet bed or equipment.
 - KLEEN KOTE can be applied as a polish to the cab to keep debris, agricultural product, mud, salt or snow from sticking to the surface. See Antique Farming Equipment Instructions for details on applying to the cab.
 - KLEEN KOTE may also be applied to the wheels and undercarriage to keep debris, agricultural products, mud, salt and snow from sticking.
 - In freezing weather, mix product as needed. Concentrate will not freeze however premix may freeze.
- **If you have any questions regarding the use of this product please feel free to contact Customer Support by telephone: 800.801.7832 – 847.639.7272 or via email: support@4progressive.com.**

REV111808