



PO Box 7277
Algonquin, IL 60102
800.801.7832 - 847.639.7272
support@4progressive.com
www.4progressive.com

Progressive
Solutions Corporation

providing "PROGRESSIVE SOLUTIONS" for your industry.

KLEEN KRETE™ - Vehicle Use Instructions

• Instructions for Using KLEEN KRETE on Vehicles

- o KLEEN KRETE is quick and easy to use and works best on dry, hardened concrete. Simply follow the tips and step by step instructions below to achieve the full benefits of this product. These instructions are specifically intended for the use of KLEEN KRETE on passenger vehicles that have come in contact with wet concrete. KLEEN KRETE provides an easy to use alternative to re-painting the vehicle.

• Tips for Use

- o Test KLEEN KRETE on an inconspicuous area prior spraying or brushing any part of the vehicle with product.
- o KLEEN KRETE's effectiveness is greatly reduced in cold weather where freezing conditions could cause the product to freeze prior to softening the concrete.
- o KLEEN KRETE's effectiveness is greatly reduced in hot, windy conditions where direct sun will cause the product to evaporate prior to softening the concrete.
- o This product does not remove paint however power washers do. Use only as much pressure as you need. Keep the tip on a 45deg. angle to the item that you are power washing and move the tip as close or as far away as needed to effectively lift and remove the concrete.
- o Refer to the product MSD Sheet for additional product information.

• Instructions

o Step 1 - Preparation

- KLEEN KRETE is packaged ready-to-use and works best when applied to dry, hard concrete. Be sure to protect concrete floors surrounding the area where KLEEN KRETE will be applied.
- Bring the vehicle into an area that is out of the sun and allow the surface to cool.

o Step 2 - Application

- Spray or brush KLEEN KRETE onto the dry, hardened concrete that you wish to remove. On smaller patches of concrete a small brush or small spray applicator will work best. KLEEN KRETE will initially foam slightly but will then subside. The product will continue to work even after the foaming action has stopped. Do NOT apply KLEEN KRETE to a hot surface. It will evaporate quickly and may damage the surface.

o Step 3 – Let Product Work

- Allow KLEEN KRETE to remain on the concrete for at least 30 minutes or until the concrete becomes soft to the touch. Heavier build-ups should be left overnight and lightly sprayed the next day approx. 10 minutes prior to removing the concrete. This is done to re-soften the concrete.

o Step 4 – Remove Softened Concrete

- After the concrete has softened, power-wash or rinse the concrete off the surface. If additional concrete remains subsequent applications of KLEEN KRETE will be necessary. Build-ups of a 1/4" (6mm) or more may require additional applications. The concrete must be allowed to dry before the next application.

o Step 5 – Wash The Surface

- After you have finished removing the hardened concrete, the entire vehicle should be wash with soap and water. It should then be rinsed thoroughly to remove any residue.

o Step 6 – Reapply Surface Protection

- KLEEN KRETE will remove all waxes or other surface protection from the vehicle's paint surface. The surface should be waxed or protected after the use of KLEEN KRETE.

• Notes

- o KLEEN KRETE is a clear liquid with an amber cast. When applied to concrete the product will foam slightly.
- o KLEEN KRETE will not affect the finish on most vehicles when used according to directions.
- o Rinse tools with soap and water after use.
- o Always wear protective clothing and eye wear.
- o Do NOT allow to freeze.

• If you have any questions regarding the use of this product please feel free to contact Customer Support by telephone: 800.801.7832 – 847.639.7272 or via email: support@4progressive.com.