



PO Box 7277  
Algonquin, IL 60102  
800.801.7832 - 847.639.7272  
support@4progressive.com  
www.4progressive.com

**Progressive**  
Solutions Corporation

providing "PROGRESSIVE SOLUTIONS" for your industry.

## KLEEN KRETE™ - Hardened Cement Removal Instructions

### • Instructions for Using KLEEN KRETE to Remove Hardened Cement

- o KLEEN KRETE is quick and easy to use and works best when applied to dry, hardened cement. Simply follow the tips and step by step instructions below to achieve the full benefits of this product.

### • Tips for Use

- o Test KLEEN KRETE on an inconspicuous area prior spraying or brushing the area with product.
- o KLEEN KRETE's effectiveness is greatly reduced in cold weather where freezing conditions could cause the product to freeze prior to softening the cement.
- o KLEEN KRETE's effectiveness is greatly reduced in hot conditions where direct sun will cause the product to evaporate prior to softening the cement.
- o This product does not remove paint however power washers do. Use only as much pressure as you need. Using a "zero" tip on your power washer will allow you to direct the water where it needs to be. Keep the tip on a 45deg. angle to the item that you are power washing and move the tip as close or as far away as needed to effectively lift and remove the cement.
- o Refer to the product MSD Sheet for additional product information.

### • Instructions

#### o Step 1 - Preparation

- KLEEN KRETE is packaged ready-to-use and works best when applied to dry, hard cement. Be sure to protect cement floors surrounding the area where KLEEN KRETE will be applied.

#### o Step 2 - Application

- Spray or brush KLEEN KRETE onto the dry, hardened cement that you wish to remove. It will initially foam slightly but will then subside. The product will continue to work even after the foaming action has stopped. Do NOT apply KLEEN KRETE to a hot surface. It will evaporate quickly and may damage the surface.

#### o Step 3 – Let Product Work

- Allow KLEEN KRETE to remain on the cement for at least 30 minutes or until the cement becomes soft to the touch. Heavier build-ups should be left overnight and lightly sprayed the next day approx. 10 minutes prior to removing the cement. This is done to re-soften the cement.

#### o Step 4 – Remove Softened Cement

- After the cement has softened, scrape or power - wash the cement off the surface. If additional cement remains subsequent applications of KLEEN KRETE will be necessary. Build-ups of a 1/4" (6mm) or more may require additional applications.

### • Technical Notes

- o KLEEN KRETE is a clear liquid with an amber cast. When applied to cement the product will foam slightly.
- o KLEEN KRETE will not affect the finish on most equipment when used according to directions and can be used as a regular maintenance product. IMPORTANT: Rinse tools with soap and water after use. Always wear protective clothing and eye wear. Do NOT allow to freeze.

### • Specifications and Compliance

- o N.A.C.E.(ASTM G-31): Non-Corrosive - CFR49 Section 173.24: Non-Corrosive - Biodegradable Oxygen Demand (B.O.D.) Test Factor (0.28): Biodegradable - DOT and IMO: Non-Hazardous - Canadian WHMIS Class "E".

• If you have any questions regarding the use of this product please feel free to contact Customer Support by telephone: 800.801.7832 – 847.639.7272 or via email: support@4progressive.com.

REV122908