



PO Box 7277
Algonquin, IL 60102
800.801.7832 - 847.639.7272
support@4progressive.com
www.4progressive.com

Progressive
Solutions Corporation

providing "PROGRESSIVE SOLUTIONS" for your industry.

KLEEN KOTE™ - Corrosion Prevention Coating Instructions

- **Instructions for Using KLEEN KOTE As a Corrosion Prevention Coating**
 - **Mix Ratio 8 to 1 thru 1 to 1**
 - Use KLEEN KOTE to prevent corrosion. It is an environmentally safe, easy to use alternative to traditional methods of preventing corrosion. KLEEN KOTE's rust inhibiting qualities will help protect against damage caused by the environmental conditions of transit, storage and use.
- **Tips for Use**
 - Remove all previously applied corrosion prevention chemicals or coatings and/or other chemicals from the area to be treated PRIOR to applying KLEEN KOTE. This will prevent any adverse reaction between KLEEN KOTE and any chemical residue previously left behind.
 - KLEEN KOTE must turn from white to clear after it is sprayed or brushed on or submerged, to provide maximum protection.
 - Reapply after every wash. Harsh chemicals are not needed to remove KLEEN KOTE. Soap and water can be used when required.
 - KLEEN KOTE can be applied to a damp surface.
 - KLEEN KOTE can NOT be applied in rainy conditions.
- **Instructions**
 - **Step 1 – Determine Your Mix Ratio**
 - Please see the above starting mix ratio. Ratios can be adjusted based upon results. They may be adjusted up or down in one part increments to achieve optimum results.
 - NOTE: The more concentrate you add the thicker and more protective KLEEN KOTE will be.
 - **Step 2 – Mixing**
 - Using a clean container, add KLEEN KOTE and water to achieve the recommended ratio for your application. Adding KLEEN KOTE to water and then adding more water will eliminate the need for mixing.
 - Do NOT mix with diesel, fuels or oils. Do NOT mix with other corrosion prevention chemicals or sea water.
 - **Step 3 – Application**
 - KLEEN KOTE may be applied at any time. For best results, the application surface should be cleaned prior to application. Remove all other chemicals prior to applying KLEEN KOTE.
 - **Step 4 – Spraying, Brushing, or Submerision**
 - Use the appropriate application method (spray, brush or submersion) and then let KLEEN KOTE change from white to clear. If KLEEN KOTE freezes on the surface you are treating, it will still work. Reapply after every use.
 - **Typical Coverage Rates for Spray Application**
 - 1 gallon of mixed KLEEN KOTE will cover approximately 2000 sq. feet (185 sq. meters), depending on the surface type. Spray on for best results and ease of application.
- **Notes**
 - DO NOT switch back and forth between KLEEN KOTE and other corrosion prevention coatings due to possible incompatibility.
 - You do not have to wait for the equipment or vehicle to dry after cleaning. KLEEN KOTE may be applied directly to the wet surface.
 - In freezing weather, mix product as needed. Concentrate will not freeze however, premix may freeze.
- **If you have any questions regarding the use of this product please feel free to contact Customer Support by telephone: 800.801.7832 – 847.639.7272 or via email: support@4progressive.com.**